## REMOTE CONTROL CODING INSTRUCTIONS

Model: Old Builders/Leader Motor S600II/ET600



## Gryphon Garage Doors 1300 959 554

## **To Delete All Coding:**

- 1. Underneath the motor there should be a button that says K2.
- 2. Press & Hold down K2 button for 10-15 seconds.
- 3. All coding will now be deleted.

## **Coding In:**

- 1. On the motor there should be four buttons.
- 2. K1 K2 K3 K4
- 3. Underneath the motor there should be a button that says K2.
- 4. Press this button.
- 5. On the handset there will be four buttons, press the button on the handset that you would like to operate your door, hold it down for 2 seconds.
- 6. Let go for 2 seconds.
- 7. Then hold for another 2 seconds.

Handset will now be coded in.

If you have any questions, please do not hesitate to contact the office.